070 Berlin ball valve, full flow

PRESSURE-TEMPERATURE DIAGRAM

The values shown by the dropping lines state the maximum limit of employment of the valves. The shown values are approximate.



