

FITTINGS FOR MULTILAYER, PEX, POLYBUTYLENE AND COPPER PIPE

510 Multi-Fit[®] fitting for multilayer, PEX and polybutylene pipe

INSTRUCTIONS



FOUR SIMPLE STEPS FOR A SAFE INSTALLATION

- 1. Cut the pipe by a pipe cutter.
- 2. Deburr the inner side of the pipe.
- 3. Insert the fitting into the pipe.
- 4. Once the threaded part of the fitting reaches the pipe, screw the tail into the pipe as far as the thread has completely entered the pipe.

THE CONNECTION IS SAFE AND EASILY REVERSIBLE.













ADVANTAGES:

- NO NEED TO REAM THE PIPE
- FIT FOR EVERY KIND OF MULTILAYER PIPE
- THE CONNECTION IS REVERSIBLE
- SUITABLE FOR SANITARY AND HEATING PLANTS
- NO NEED TO PRESS. NO NEED TO TIGHTEN. NO SPECIAL EQUIPMENT IS REQUIRED FOR THE INSTALLATION



The fittings are supplied with an o-ring for conical seats and a flat washer for flat seats.




MANIFOLD WATER DISTRIBUTION SYSTEM

The Multi-fit[®] system is completed with the installation of the distribution manifold Art. 465 and built-in box Art. 499. This lay-out allows the planning engineer and installer to work in complete safety, also ensuring high quality system standards.





FITTINGS FOR MULTILAYER, PEX, POLYBUTYLENE AND COPPER PIPE



ADVANTAGES:

- NO MORE BUILD-IN TEE AND ELBOW JUNCTIONS
- NO MORE LEAKAGES
- REALLY MAKE THE MOST OF MULTILAYER PIPING FLEXIBILITY AND INSTALLATION SPEED
- IMPROVE THE WATER FLOW
- MAKE REPAIRS EASY AND FAST
- EACH ENDPOINT CONNECTED TO A SINGLE MANIFOLD OUTLET

USE OF THE FITTINGS FOR MULTILAYER, PEX AND POLYBUTYLENE PIPE





FITTINGS FOR MULTILAYER, PEX, POLYBUTYLENE AND COPPER PIPE

